

NEWMAN DRIV



ZONE 4

NEWMAN DRIVE

ZONE 3

## **Emergency Evacuation Zone Allocation**

In the event of a fire, evacuate people in the following areas to the zone stated.

Assembly Zone 1	Function Room, Kitchen, Admin, H/Keeping, Stores
Assembly Zone 2	House Guests Block 6 & 7, Stores, Meeting Room 6, Guest Laundry
Assembly Zone 3	House Guests Block 5 & 4
Assembly Zone 4	Restaurant & Bar Staff & Patrons, Reception/Admin Staff, Maintenance
Assembly Zone 5	House Guests Block 2, Residents of Staff Quarters

ZONE 2

